

## Procedure for maintaining anilox rollers

1. Apply Pro Gravure Cleaner to the anilox roller with our Anilox Sponge and spread it evenly over the entire surface of the anilox roller.
2. Let the Pro Gravure Cleaner work for about 10 minutes (heavily soiled anilox rollers may need 15-20 minutes to take effect). Please keep the anilox roller wet during the entire process with the Pro Gravure Cleaner in order to prevent the Pro Gravure Cleaner from drying on the anilox roller.
3. After 10-20 minutes, wet the anilox roller with Pro Gravure Cleaner again and then work the Pro Gravure Cleaner into the cells of the anilox roller with our special Steel brush.
4. Wet the anilox roller again and wait 5 minutes before cleaning the roller with lots of clean water and White Hex Cloth and finish with a dry White Hex Cloth.

### Products Used for cleaning



White Hex Cloth



PRO Gravure Cleaner



Anilox Sponge



Steel brush



Protective glasses



Gloves

**DANGER: Pro Gravure Cleaner is corrosive. Please use protective glasses and gloves. MSDS can be downloaded on [www.progravurecleaner.com](http://www.progravurecleaner.com)**